




Quick Start Guide

Contents


*	Specification	p.01
	Panel Removal	p.02
*	Front Panel I/O Connections	p.03
*	Component List	p.04
*	Motherboard Installations	p.05
	SSD / HDD Installation	p.06
\$	GPU & PSU Installation	p.07
	CPU Cooler / Fan Installation	p.08
	Package Contents & Warranty	p.09



Specifications

Туре	Specification
Motherboard Support	mATX, ITX
Dimensions (with ext. chamber)	391(L) x 205(W) x 362(H)mm
3.5" HDD Drive Bay	2 (dependent on PSU position)
2.5" SSD Drive Bay	2 (dependent on PSU position)
Expansion Slots	5
Maximum GPU Length	355mm / 280mm
Maximum CPU Cooler Height	165mm
Maximum PSU Length	(dependent on GPU Length)

Panel Removal



outwards with controlled force.

Front Panel I/O Connections





These cables are connected to the motherboard for the power button (power sw), reset button, HDD LED, and power LED (P+ / P-).



HD AUDIO

This connector attaches to your sound card or motherboard and is used to provide the front panel mic input and headphone output.




USB 3.0 CONNECTOR

This cable connects to the USB 3.0 header on the motherboard to enable the front USB 3.0 ports.


Component List

VISUAL	ITEM	QTY	APPLICATION
A ************************************	Motherboard & SSD screw	24	Motherboard and 2.5 hard drive installation
В	HDD mount screw	20	3.5 hard drive installation
С	PSU & Rear expansion slot screw	4	Power supply installation Mounting of GPU and other expansion cards
D	Snap Buckle	2	Clips for the panel
E	Cable tie	8	Cable management
F	Cable tie (reusable)	8	Cable management

Motherboard Installation




SSD / HDD Installation




GPU Installation

Graphics Processing Unit and other expansion cards



CPU Cooler / Fan Installation



Package Contents

- 1 x TECWARE Fusion 2 Case
- 1 x Bag of Accessories

Warranty

• 1 Year. Please contact your local distributor for support.

TECWARE